Metal Light

MLHV32

Energizer EVEREADY RAY VAC.

The *EVEREADY*. Metal flashlight delivers a balance of bright light and impressive runtime, bundled into a compact size. The light features a durable metal construction for added reliability. The textured grip allows the light to fit securely in your hand, while the lanyard attachment makes it easy to transport.

Lumens F	Runtime	Beam Distance	npact	DESIGN BENEFITS
FLISTANDARD FLISTANDARD 50 C 15h FLISTANDARD FLISTANDARD FLISTANDARD FLISTANDARD FLISTANDARD FLISTANDARD FLISTANDARD FLISTANDARD				 ✓ Strong metal construction ✓ Lightweight and compact for ease of carrying and storing. ✓ Lanyard easily attaches to your wrist for secure transport ✓ Easy to use PERFORMANCE BENEFITS
				 ✓ Up to 5X brighter than standard LED technology ✓ Long runtime
				LIGHT AND POWER SOURCE ✓ Features LED technology ✓ Operates on 3 AAA batteries
				PRODUCT SPECIFICATIONS Weight: 35 Grams / 1.23 Ounces
	BATTERY	SPECIFICATIO	DNS	
Battery Type	ENR IV		d ROV HE Alkaline	Dimensions: 88mm x 26mm x 26mm 3.46" x 1.02" x 1.02"
Battery Size	AAA			ELECTRICAL CHARACTERISTICS
Number of Ce				Nominal Power Consumption: 0.42 W
	BATTER	Y PERFORMAN		Batteries: 3 AAA Energizer E92 4.5V dc
Modes	Lumens	Runtime	Beam Distance	-
	(Im)	(h)	(m)	LED Specifications: LED 3.0V cc / 140 mA
On	50	15	30	DISCLAIMERS
BATTERY SPECIFICATIONS				Tested according to ANSI FL1 Standards.
Battery Type		ID CZn and RO	V CZn HD	
Battery Size	AAA			
Number of Ce				CERTIFICATES AND COMPLIANCE
		PERFORMAN		EMC, EN62471
Modes	Lumens	Runtime	Beam Distance	EMC, EN62471
	(lm)	(h)	(m)	Publish Date: 9 June 2021
On	50	7	30	
Modes				
On				

Before using your flashlight, please read all instructions and cautionary marking on the package and the light. This datasheet contains information specific to products manufactured at the time publication. Contents do not constitute a claim or warranty. ©2020 Energizer

OPERATING INSTRUCTIONS

1. Press on/off button to turn on.

BATTERY CHANGING INSTRUCTIONS

- 1. Batteries (3X AAA) are user replaceable.
- 2. Unscrew tail cap and remove battery cartridge. Insert batteries into the cartridge with (-) end against spring. Reinsert cartridge into light the direction the arrow on the cartridge shows.